

CESSNA L-19, 305, 0-1A thru H0-1G

308	Windshield	.125	0613050
305	Rear windshield	.100	0612134
320	Door window - left or right	.125	0611218
321	Front cabin top window (4 per aircraft)	.080	0611098-1
322	Rear observer window - left or right	.080	0611158
323	Top rear window - left or right	.080	0611099-1

CESSNA 120 & 140 s/n 8001 thru 8799, 1946

301	Windshield	.125	0411172-3
342	Door window - left or right	.060	0411182
343	Rear window - left or right	.060	0412145
344	Skylight - left or right	.060	0411144

CESSNA 120 & 140 s/n 8800 thru 15075, 1946 thru 1949

300	Windshield	.125	0411172-5
342	Door window - left or right	.060	0411182
343	Rear window - left or right	.060	0412145
344	Skylight - left or right	.060	0411144

CESSNA 140A s/n 15200 thru 15724, 1949 thru 1951

303	Windshield	.125	0413419-203
342	Door window - left or right	.060	0411182
343	Rear window - left or right	.060	0412145
344	Skylight - left or right	.060	0411144
373	Landing light lens	.100	0523115-5

CESSNA**150**

s/n 17001 thru 15079405, 1959 thru 1977

CESSNA AEROBAT**150**

s/n A1500001 thru A1500734, 1970 thru 1977

REIMS AVIATION**F150**

s/n F150-0001 thru F15001428

REIMS AVIATION AEROBAT**FA150**

s/n FA1500001 thru FRA1500337

303	Windshield	s/n 17001 thru 15067198 s/n 15069309 thru 15073658 s/n A1500001 thru A1500342 s/n F150-0001 thru F150-0219 s/n F150-0390 thru F15000863 s/n FA1500001 thru FA1500166	.125	0413419-203
303/302	Windshield with compass mount (continued)	s/n 15067199 thru 15069308 s/n 15073659 thru 15079405 s/n A1500343 thru A1500734 s/n F150-0220 thru F150-0389 s/n F15000864 thru F15001428 s/n FA1500167 thru FRA1500337	.125	0413419-201

NEW	LP#	DESCRIPTION	THICKNESS	OEM PART NO.
-----	-----	-------------	-----------	--------------

CESSNA 150, CESSNA AEROBAT 150, REIMS AVIATION F150, REIMS AVIATION AEROBAT FA150 (Continued)

342	Door window - left or right	s/n 17001 thru 15061532	.060	0411182
364	Door window - left or right	s/n 15061533 thru 15064532 s/n F150-0001 thru F150-0067	.060	0413390-20
365	Door window - left or right*	* s/n 15064533 thru 15079405 s/n A1500001 thru A1500734 s/n F150-0068 thru F15001428 s/n FA1500001 thru FRA1500337	.100	0413033-13, -14
487	Domed door window - left - STC pending*		.125	
488	Domed door window - right - STC pending*		.125	
343	Rear window - left or right	s/n 17001 thru 59018	.060	0412145
363	Rear window - left or right	s/n 15059019 thru 15060087	.060	0412522-7
360	Rear windshield	s/n 15060088 thru 15079405 s/n A1500001 thru A1500734 s/n F150-0001 thru F15001428 s/n FA1500001 thru FA1500336	.125	0412020-10
344	Skylight	s/n 15071129 thru 15079405 s/n A1500001 thru A1500734 s/n F15000530 thru F15001428 s/n FA1500001 thru FA1500120 s/n FRA1500121 thru FRA1500337	.060	0411144
373	Landing light lens	s/n 17001 thru 15072003 s/n A1500001 thru A1500226 s/n F150-0001 thru F15000658 s/n FA1500001 thru FA1500081	.100	0523115-5

CESSNA 152 s/n 15279406 thru 15286033, 1978 thru 1985
CESSNA AEROBAT A152 s/n A1520735 thru A1521049, 1978 thru 1985
REIMS AVIATION F152 s/n F15201429 thru F15201952
REIMS AVIATION AEROBAT FA152 s/n FA1520337 thru FA1520387

303/302	Windshield - with compass mount		.125	0413419-201
365	Door window - left or right		.100	0413033-15,-16
487	Domed door window - left - STC pending		.125	
488	Domed door window - right - STC pending		.125	
360	Rear windshield		.125	0412020-10
344	Skylight		.060	0411144

CESSNA 170 s/n 18003 thru 18728, 1948 thru 1949

310	Windshield		.125	0510000-6
374	Door window - left or right		.125	0511106-3
344	Skylight		.060	0411144

CESSNA 170A s/n 18729 thru 20266, 1950 thru 1951

306	Windshield		.125	0510000-15
312/CON	Windshield - STC Conversion - Removes center strap - s/n 18729 thru 20266 - Compass does not mount on windshield.		.187	
312/CMB	Windshield - STC Conversion - Removes center strap - s/n 18729 thru 20266 - Compass mounting block bonded to windshield.		.187	
SP-CMKT SP-CHKT	Complete Airpath compass with housing & mounting bracket - attaches to CMB windshield - see pg. 5 Compass housing & mounting bracket - less compass - attaches to CMB windshield - see pg. 5			
376	Door window - left or right		.125	0511106-104
370	Rear window - left or right		.060	0512000-54
373	Landing light lens		.100	0523115-5

CESSNA 170B s/n 20267 thru 27169, 1952 thru 1955

312	Windshield		.125	0510001-6
312/CON	Windshield - STC Conversion - Removes center strap - s/n 20267 thru 27169 - Compass does not mount on windshield.		.187	
312/CMB	Windshield - STC Conversion - Removes center strap - s/n 20267 thru 27169 - Compass mounting block bonded to windshield.		.187	
	(continued)			

NEW	LP#	DESCRIPTION	THICKNESS	OEM PART NO.
-----	-----	-------------	-----------	--------------

CESSNA 170B (Continued)

SP-CMKT SP-CHKT	Complete Airpath compass with housing & mounting bracket - attaches to CMB windshield - see pg. 5 Compass housing & mounting bracket - less compass - attaches to CMB windshield - see pg. 5			
376	Door window - left		.125	0511106-104
376	Door window - right	s/n 20267 thru 26995	.125	0511106-104
374	Door window - right	s/n 26996 thru 27169	.125	0510006-3
370	Rear window - left or right	s/n 20267 thru 26504	.060	0512000-54
388	Rear window - left or right	s/n 26505 thru 27169	.060	0591200-3
373	Landing light lens		.100	0523115-5

CESSNA 172 s/n 28000 thru 17250572, 1956 thru 1963
P172 s/n 17257120 thru 17257188

REIMS AVIATION F172 s/n F172-0001 thru F172-0018

312	Windshield	s/n 28000 thru 47746	.125	0510001-6
312/CON	Windshield - STC Conversion - Removes center strap - s/n 28000 thru 47746 - Compass does not mount on windshield.		.187	
312/CMB	Windshield - STC Conversion - Removes center strap - s/n 28000 thru 47746 - Compass mounting block bonded to windshield.		.187	
311	Windshield	s/n 17247747 thru 17249544	.125	0513300-16
311/CON	Windshield - STC Conversion - Removes center strap - s/n 17247747 thru 17249544 - Compass does not mount on windshield.		.187	
311/CMB	Windshield - STC Conversion - Removes center strap - s/n 17247747 thru 17249544 - Compass mounting block bonded to windshield.		.187	
SP-CMKT SP-CHKT	Complete Airpath compass with housing & mounting bracket - attaches to CMB windshield - see pg. 5 Compass housing & mounting bracket - less compass - attaches to CMB windshield - see pg. 5			
313	Windshield	s/n 17249545 thru 17250572 s/n 17257120 thru 17257188 s/n F172-0001 thru F172-0018	.125	0513230-10
369	Door window - left or right - openable		.125	0711051-1
374	Door window - right - nonopenable	s/n 28000 thru 17248181	.125	0511106-3
375	Door window - right - nonopenable	s/n 17248182 thru 17250572 s/n F172-0001 thru F172-0018	.125	1210040-23
388	Rear side window - left or right	s/n 28000 thru 17249544	.060	0591200-3
385	Rear side window - left*		.125	0512030-13
386	Rear side window - right*	* s/n 17249545 thru 17257161 s/n F172-0001 thru F172-0559	.125	0512030-14
389	Rear windshield	s/n 17249545 thru 17250572 s/n F172-0001 thru F172-0559	.125	0512100-9
373	Landing light lens		.100	0523115-5

CESSNA SKYHAWK or SKYHAWK II 172 s/n 17250573 thru 17275759, 1964 thru 1982

REIMS AVIATION F172 s/n F172-0019 thru F17202194

345	Windshield	s/n 17250573 thru 17272884 s/n F172-0019 thru F17201909	.125	0513230-12
337	Windshield	s/n 17272885 thru 17275759 s/n F17201910 thru F17202194	.125	0513230-27
369	Door window - left or right - openable		.125	0711051-1
375	Door window - right - nonopenable		.125	1210040-23
385	Rear side window - left*		.125	0512030-13
386	Rear side window - right*	* s/n 17250573 thru 17257161 s/n F172-0001 thru F172-0559	.125	0512030-14
348	Rear side window - left**		.125	0512180-5
349	Rear side window - right**	** s/n 17257162 and up s/n F172-0560 thru F17201234	.125	0512180-6
389	Rear windshield		.125	0512100-9
346	Skylight	s/n 17259224 and up s/n F17200755 and up	.080	0511797-2
373	Landing light lens	s/n 17250573 thru 17259223 s/n F172-0019 thru F17200804	.100	0523115-5

NEW	LP#	DESCRIPTION	THICKNESS	OEM PART NO.
-----	-----	-------------	-----------	--------------

CESSNA SKYHAWK or SKYHAWK II 172P s/n 17275760 thru 17276673, 1983 thru 1986

CUTLASS or CUTLASS II 172Q s/n 17275869 thru 17276516

REIMS AVIATION F172 s/n F17202195 and up

353	Windshield		.250	0513230-32
423	Door window - left or right		.250	0517024-9
424	Door window - right - nonopenable		.250	0517024-11
348	Rear side window - left		.125	0512180-5
349	Rear side window - right		.125	0512180-6
389	Rear windshield		.125	0512100-9
346	Skylight		.080	0511797-2

CESSNA HAWK XP or HAWK XP II R172 s/n R1722000 thru R1723454, 1977 thru 1981

REIMS AVIATION FR172K s/n FR17200591 thru FR17200675

359	Windshield	s/n R1722000 thru R1723199 s/n FR17200591 thru FR17200655	.250	0513230-20
353	Windshield	s/n R1723200 thru R1723454 s/n FR17200656 thru FR17200675	.250	0513230-32
367	Door window - left or right - openable		.187	0517024-1
368	Door window - right - nonopenable		.187	0517024-5
348	Rear side window - left		.125	0512180-5
349	Rear side window - right		.125	0512180-6
389	Rear windshield		.125	0512100-9
346	Skylight		.080	0511797-2

CESSNA CUTLASS RG & CUTLASS RGII 172 s/n 172RG0001 thru 172RG1191, 1980 thru 1985

353	Windshield		.250	0513230-32
367	Door Window - left or right - openable	s/n 172RG0001 thru 172RG1099	.187	0517024-1
423	Door window - left or right - openable	s/n 172RG1100 and up	.250	0517024-9
368	Door window - right - nonopenable	s/n 172RG0001 thru 172RG1099	.187	0517024-5
425	Door window - right - nonopenable PMA Pending	s/n 172RG1100 and up	.250	0517024-12
348	Rear side window - left		.125	0512180-1
349	Rear side window - right		.125	0512180-2
389	Rear windshield		.125	0512100-9
346	Skylight		.080	0511797-2

CESSNA SKYLARK 175 s/n 55001 thru 17557119, 1958 thru 1962

314	Windshield	s/n 55001 thru 17557002	.125	0513300-8
314/CON	Windshield - STC Conversion - Removes center strap - s/n 55001 thru 17557002 - Compass does not mount on windshield.		.187	
314/CMB	Windshield - STC Conversion - Removes center strap - s/n 55001 thru 17557002 - Compass mounting block bonded to windshield.		.187	
311	Windshield	s/n 17557003 thru 17557119	.125	0513300-16
311/CON	Windshield - STC Conversion - Removes center strap - s/n 17557003 thru 17557119 - Compass does not mount on windshield.		.187	
311/CMB	Windshield - STC Conversion - Removes center strap - s/n 17557003 thru 17557119 - Compass mounting block bonded to windshield.		.187	
SP-CMKT SP-CHKT	Complete Airpath compass with housing & mounting bracket - attaches to CMB windshield - see pg. 5 Compass housing & mounting bracket - less compass - attaches to CMB windshield - see pg. 5			
369	Door window - left		.125	0711051-1
374	Door window - right - nonopenable	s/n 55001 thru 17556927	.125	0511106-3
375	Door window - right - nonopenable	s/n 17556928 thru 17557119	.125	1210040-23
388	Rear window - left or right		.060	0591200-3
373	Landing light lens		.100	0523115-5

CESSNA CARDINAL 177 s/n 17700001 thru 17702752, 1968 thru 1978

177RG s/n 177RG0001 thru 177RG1366, 1971 thru 1978

REIMS AVIATION F177RG s/n F177RG0001 thru F177RG0177, 1971 thru 1977

329	Windshield		.187	1710000-9
329.250	Windshield - with milled edge - STC Conversion		.250	
525	Door window - left		.125	1717031-9
	(continued)			

NEW	LP#	DESCRIPTION	THICKNESS	OEM PART NO.
-----	-----	-------------	-----------	--------------

CESSNA CARDINAL 177, 177RG, REIMS AVIATION F177RG (Continued)

532	Door window - right		.125	1717031-10
530	Vent window - left or right		.125	
527	Rear window - left		.125	1712000-5
528	Rear window - right		.125	1712000-6
529	Rear windshield		.125	1712000-7
533	Landing light lens	s/n 17700001 thru 17701370	.080	1221060-3
534	Landing light lens	s/n 17701371 thru 17701530 s/n 177RG0001 thru 177RG0212 s/n F177RG0001 thru F177RG0042	.080	1221060-5

CESSNA 180 s/n 30000 thru 18051183, 1953 thru 1962

309	Windshield	s/n 30000 thru 31260	.187	0791300-4
315	Windshield	s/n 31261 thru 50355	.250	0791300-7
315/CON	Windshield STC Conversion Removes center strap Compass does not mount on windshield.	s/n 30000 thru 50355	.250	
315/CMB	Windshield STC Conversion Removes center strap Compass mounting block bonded to windshield.	s/n 30000 thru 50355	.250	
316	Windshield	s/n 50356 and up	.250	0713100-10
316/CON	Windshield STC Conversion Removes center strap Compass does not mount on windshield	s/n 50356 and up	.250	
316/CMB	Windshield STC Conversion Removes center strap Compass mounting block bonded to windshield.	s/n 50356 and up	.250	
SP-CMKT SP-CHKT	Complete Airpath compass with housing & mounting bracket - attaches to CMB windshield - see pg. 5 Compass housing & mounting bracket - less compass - attaches to CMB windshield - see pg. 5			
369	Door window - left or right		.125	0711051-1
362	Rear window - left or right		.060	0710108-3
381	Landing light lens		.080	0722100-4

CESSNA SKYWAGON 180 s/n 18051184 thru 18052384, 1963 thru 1973

185 s/n 185-0001 thru 18502310, 1961 thru 1973

316	Windshield		.250	0713100-10
316/CON	Windshield - STC Conversion - Removes center strap - Compass does not mount on windshield.		.250	
316/CMB	Windshield - STC Conversion - Removes center strap - Compass mounting block bonded to windshield.		.250	
SP-CMKT SP-CHKT	Complete Airpath compass with housing & mounting bracket - attaches to CMB windshield - see pg. 5 Compass housing & mounting bracket - less compass - attaches to CMB windshield - see pg. 5			
369	Door window - left or right - openable		.125	0711051-1
384	Center window - left or right	s/n 18051313 thru 18052384 s/n 185-0001 thru 18502310	.060	0700112-1
362	Rear window - left or right	s/n 18051184 thru 18051312	.060	0710108-3
361	Rear window - left or right	s/n 18051313 and up s/n 1850001 and up	.060	0700111-1
381	Landing light lens	s/n 18051184 thru 18052284 s/n 185-0001 thru 18502090	.080	0722100-4

CESSNA SKYWAGON 180 s/n 18052385 thru 18053203, 1974 thru 1981

185 s/n 18502311 thru 18504448, 1974 thru 1985

316	Windshield		.250	0713100-10
316/CON	Windshield - STC Conversion - Removes center strap - Compass does not mount on windshield.		.250	
	(continued)			

NEW	LP#	DESCRIPTION	THICKNESS	OEM PART NO.
-----	-----	-------------	-----------	--------------

CESSNA SKYWAGON 180, 185 (Continued)

316/CMB	Windshield - STC Conversion - Removes center strap Compass mounting block bonded to windshield.	.250	
SP-CMKT SP-CHKT	Complete Airpath compass with housing & mounting bracket - attaches to CMB windshield Compass housing & mounting bracket - less compass - attaches to CMB windshield		
369	Door window - left or right - openable	.125	0711051-1
402	Lower door window - left or right	.125	0717013-7
404	Domed door window - left	.125	0717019-1
405	Domed door window - right	.125	0717019-2
387	Center window - left or right	.125	0700112-3
361	Rear window - left or right	.060	0700111-1
346	Skylight	.060	0511797-2

CESSNA SKYLANE 182 s/n 33000 thru 18253598, 1956 thru 1961

315	Windshield s/n 33000 thru 51556	.250	0791300-7
315/CON	Windshield s/n 33000 thru 51556 STC Conversion Removes center strap Compass does not mount on windshield.	.250	
315/CMB	Windshield s/n 33000 thru 51556 STC Conversion Removes center strap Compass mounting block bonded to windshield.	.250	
316	Windshield s/n 51557 thru 18253598	.250	0713100-10
316/CON	Windshield s/n 51557 thru 18253598 STC Conversion Removes center strap Compass does not mount on windshield.	.250	
316/CMB	Windshield s/n 51557 thru 18253598 STC Conversion Removes center strap Compass mounting block bonded to windshield.	.250	
SP-CMKT SP-CHKT	Complete Airpath compass with housing & mounting bracket - attaches to CMB windshield Compass housing & mounting bracket - less compass - attaches to CMB windshield		
369	Door window - left or right - openable	.125	0711051-1
375	Door window - right - nonopenable s/n 18253008 thru 18253598	.125	1210040-23
384	Center window - left or right s/n 52359 thru 18253598	.060	0700112-1
362	Rear window - left or right s/n 33000 thru 52358	.060	0710108-3
362.125	Rear window - left or right - PMA Pending s/n 34754 thru 51477	.125	0710108-1
361	Rear window - left or right s/n 52359 thru 18253598	.060	0700111-1
381	Landing light lens	.080	0722100-4

CESSNA SKYLANE 182 s/n 18253599 thru 18264295, 1962 thru 1975

338	Windshield s/n 18253599 thru 18255844	.187	0713600-8
339/CON	Windshield s/n 18253599 thru 18255844 STC Conversion Removes center strap Compass does not mount on windshield.	.250	
339/CMB	Windshield s/n 18253599 thru 18255844 STC Conversion Removes center strap Compass mounting block bonded to windshield.	.250	
SP-CMKT SP-CHKT	Complete Airpath compass with housing & mounting bracket - attaches to CMB windshield Compass housing & mounting bracket - less compass - attaches to CMB windshield		
339	Windshield - with compass mount s/n 18255845 thru 18264295	.250	0713287-11
391	Door window - left or right - openable	.125	0711051-7
392	Door window - right - nonopenable	.125	0717010-18
395	Rear side window - left s/n 18253599 thru 18255058	.125	0711600-19
396	Rear side window - right s/n 18253599 thru 18255058	.125	0711600-20
371	Rear side window - left s/n 18255059 thru 18264295	.125	0711675-11
372	Rear side window - right s/n 18255059 thru 18264295	.125	0711675-12
	(continued)		

NEW	LP#	DESCRIPTION	THICKNESS	OEM PART NO.
-----	-----	-------------	-----------	--------------

CESSNA SKYLANE 182 (Continued)

393	Rear windshield - left	s/n 18253599 thru 18255058	.125	0711600-11
394	Rear windshield - right	s/n 18253599 thru 18255058	.125	0711600-10
397	Rear windshield	s/n 18255059 thru 18264295	.187	0711675-10
346	Skylight	s/n 18255059 and up	.080	0511797-2
381	Landing light lens	s/n 18253599 thru 18260825	.080	0722100-4

CESSNA SKYLANE and SKYLANE II 182 REIMS AVIATION s/n 18264296 and up, 1976 and up F182 s/n F18200001 thru F18200169, 1976 thru 1980

318	Windshield	s/n 18264296 thru 18265965 s/n F18200001 thru F18200064	.250	0713538-1
317	Windshield	s/n 18265966 and up s/n F18200065 thru F18200169	.250	0713538-3
391	Door window - left or right - openable		.125	0711051-6
392	Door window - right - nonopenable		.125	0717010-16
371	Rear window - left		.125	0711800-11
372	Rear window - right		.125	0711800-12
397	Rear windshield	s/n 18262466 thru 18267300	.187	0711800-10
390	Rear windshield	s/n 18267301 and up	.187	0711800-18
346	Skylight		.080	0511797-2

CESSNA SKYLANE RG & RGII REIMS AVIATION s/n R18200001 and up, 1978 & up TURBO SKYLANE RG & RGII TR182 s/n R18200001 and up, 1978 & up FR182 s/n FR18200001 thru FR18200070, 1978 thru 1980

317	Windshield		.250	0713538-3
391	Door window - left or right - openable		.125	0711051-6
392	Door window - right - nonopenable		.125	0717010-16
371	Rear window - left		.125	0711800-11
372	Rear window - right		.125	0711800-12
397	Rear windshield	s/n R18200001 thru R18201313 s/n FR18200001 thru FR18200045	.187	1711800-10
390	Rear windshield	s/n R18201314 & up s/n FR18200046 & up	.187	0711800-18
346	Skylight		.060	0511797-2

CESSNA AGWAGON, AGPICKUP, AGTRUCK 188 thru A188B REIMS AVIATION s/n 188-0001 & up, 1966 & up AGHUSKY T188C s/n T18803297T & up, 1979 & up

377	Windshield		.150	1610003-13
379	Door window - left or right - no vent	s/n 188-0001 thru 18800572	.100	1610004-21
410	Door window - left - with vent cutout*		.187	1610032-15
412	Door window - right - with vent cutout*		.187	1610032-16
411	Vent window - left*		.250	1610032-13
413	Vent window - right*	* s/n 18801825(T) and up s/n T18803307T, T18803308T, T18803325T & up	.250	1610032-12
378	Rear windshield**		.125	1610016-9
414	Skylight - left**		.080	1610029-1
415	Skylight - right**	** s/n 188-0275 and up s/n T18803307T and up	.080	1610029-2
381	Landing light lens - left	s/n 188-0001 thru 18800707	.080	0722100-4
416	Landing light lens - left - Non-PMA	s/n 18800708 thru 18800832	.125	0722100-15
382	Landing light lens - right -	s/n 188-0275 thru 18800707	.100	0722100-10
417	Landing light lens - right - Non-PMA	s/n 18800708 thru 18800832	.125	0722100-16

CESSNA 190 & 195 s/n 7001 thru 7999, 1948 thru 1953 s/n 16000 thru 16183

307	Windshield		.187	0311001-19
731	Center forward window - left		.125	0311001-21
732	Left front sliding window		.125	0311245
733	Right front door window		.125	0311204-3
734	Rear center window - left or right		.125	0311001-22
735	Rear window - left or right		.125	0311001-23
736	Right front window		.125	0311001-20

NEW	LP#	DESCRIPTION	THICKNESS	OEM PART NO.
-----	-----	-------------	-----------	--------------

CESSNA 205 s/n 205-0001 thru 205-0577, 1963 and 1964

325	Windshield		.187	1213400-15
326/CON	Windshield - STC Conversion - Removes center strap - Compass does not mount on windshield.		.250	
326/CMB	Windshield - STC Conversion - Removes center strap - Compass mounting block bonded to windshield.		.250	
SP-CMKT SP-CHKT	Complete Airpath compass with housing & mounting bracket - attaches to CMB windshield - see pg. 5 Compass housing & mounting bracket - less compass - attaches to CMB windshield - see pg. 5			
391	Door window - left		.125	0711051-6
392	Door window - right - nonopenable		.125	0717010-16
220	Side window - middle - left or right		.125	1211400-16
420	Baggage door window	s/n 205-0001 thru 205-0383	.125	1211448-7
217	Baggage door window	s/n 205-0384 thru 205-0577	.125	1211448-24
221	Rear window - right		.125	1211400-14
222	Rear windshield - center		.125	1211400-19
223	Rear windshield - left		.125	1211400-17
224	Rear windshield - right		.125	1211400-18
381	Landing light lens		.080	0722100-4

CESSNA SUPER SKYWAGON 206, SUPER SKYWAGON U206, STATIONAIR s/n 206-0001 thru 206-0275
SUPER SKYLANE P206 s/n U206-0276 & up

s/n P206-0001 thru P20600647

325	Windshield*		.187	1213400-15
326/CON	Windshield - STC Conversion - Removes center strap* - Compass does not mount on windshield.		.250	
326/CMB	Windshield - STC Conversion - Removes center strap* - Compass mounting block bonded to windshield. * 206 s/n 206-0001 thru 206-0275 U206 s/n U206-0276 thru U206-0437 P206 s/n P206-0002 thru P206-0160		.250	
SP-CMKT SP-CHKT	Complete Airpath compass with housing & mounting bracket - attaches to CMB windshield - see pg. 5 Compass housing & mounting bracket - less compass - attaches to CMB windshield - see pg. 5			
326	Windshield with compass mount	U206 s/n U206-0438 and up P206 s/n P206-0161 thru P20600647	.250	1213400-200
391	Door window - left		.125	0711051-6
392	Door window - right - nonopenable		.125	0717010-16
391	Door window - right - openable		.125	0711050-28
218	Cargo door window - forward*		.125	1211670-4
219	Cargo door window - rearward*	* s/n 206-0001 thru 206-0275 s/n U206-0276 & up	.125	1211673-5
217	Baggage door window	s/n P206-0001 thru P20600647	.125	1211448-24
220	Side window - center forward - left		.125	1211400-16
220	Side window - center forward - right*	* s/n P206-0001 thru P20600647	.125	1211400-16
221	Rear side window - left		.125	1211400-14
221	Rear side window - right	s/n P206-0001 thru P20600647	.125	1211400-14
222	Rear windshield - center		.125	1211400-19
223	Rear windshield - left		.125	1211400-17
224	Rear windshield - right		.125	1211400-18
381	Landing light lens	s/n 206-0001 thru U20601700 s/n P206-0001 thru P20600647	.080	0722100-4

CESSNA SKYWAGON, STATIONAIR 207 s/n 20700001 and up, 1969 and up

330	Windshield		.250	1213800-200
391	Front door window - left		.125	0711051-6
392	Front door window - right - nonopenable		.125	0717010-16
391	Front door window - right - openable		.125	0711051-6
340	Center window - left or right		.125	1212846-1
220	Center window - rearward - left		.125	1211400-16
221	Rear side window - left		.125	1211400-14
218	Cargo door window - forward		.125	1211670-4
219	Cargo door window - rearward		.125	1211673-5
222	Rear windshield - center		.125	1211400-19
	(continued)			

NEW	LP#	DESCRIPTION	THICKNESS	OEM PART NO.
-----	-----	-------------	-----------	--------------

CESSNA SKYWAGON, STATIONAIR 207 (Continued)

223	Rear windshield - left	.125	1211400-17
224	Rear windshield - right	.125	1211400-18
381	Landing light lens	.080	0722100-4

CESSNA CARAVAN I **208 & 208A** s/n 20800001 and up
208B s/n 208B0001 and up
CARGOMASTER **208** s/n 20800113 and up
SUPER CARGOMASTER 208B s/n 208B0045 and up

1010	Windshield - left	.312	2613088-1
1011	Windshield - right	.312	2613088-2
1012	Crew door window - left front	.250	2617059-1
1013	Vent window - left	.375	2617024-4
1014	Crew door window - right front	.250	2617059-2
1006	Cabin window - left #2 and right #2 & #4*	.187	2611024-1
1006	Passenger door window - right #5*	.187	2611024-1
1006	Cargo door window - forward & rearward - left #4 & #5*	.187	2611024-1
1007	Cabin window - left #3 and right #3*	.187	2611024-2
1008	Rear window - left #6*	.187	2612057-1
1009	Rear window - right #6*	.187	2612057-2
	* PMA Pending		

CESSNA 210 s/n 21057001 thru 21057840, 1960 thru 1961

327	Windshield	.250	1213000-20
327/CON	Windshield - STC Conversion - Removes center strap - Compass does not mount on windshield.	.250	
327/CMB	Windshield - STC Conversion - Removes center strap - Compass mounting block bonded to windshield.	.250	
SP-CMKT SP-CHKT	Complete Airpath compass with housing & mounting bracket - attaches to CMB windshield - see pg. 5 Compass housing & mounting bracket - less compass - attaches to CMB windshield - see pg. 5		
366	Front door window - left s/n 57001 thru 57575	.125	1210040-7
347	Front door vent window - left s/n 57001 thru 57575	.125	1210041-2
369	Front door window - left s/n 21057576 thru 21057840	.125	0711051-2
375	Front door window - right s/n 21057001 thru 21057840	.125	1210040-8
384	Center window - left or right s/n 21057576 thru 21057840	.060	0700112-1
362	Rear window - left or right s/n 21057001 thru 21057575	.060	0710108-3
361	Rear window - left or right s/n 21057576 thru 21057840	.060	0700111-1
381	Landing light lens	.080	0722100-4

CESSNA CENTURION 210 s/n 21057841 thru 21058818, 1962 thru 1966 s/n T210-0001 thru T210-0197 s/n 21058511 thru 21058715

325	Windshield s/n 21057841 thru 21058220 s/n 21058511 thru 21058715	.187	1213400-15
324	Windshield s/n 21058221 thru 21058510	.187	1213400-24
326/CON	Windshield - STC Conversion - Removes center strap* - Compass does not mount on windshield. * 210 s/n 21057841 thru 21058715	.250	
326/CMB	Windshield - STC Conversion - Removes center strap* - Compass mounting block bonded to windshield. * 210 s/n 21057841 thru 21058715	.250	
SP-CMKT SP-CHKT	Complete Airpath compass with housing & mounting bracket - attaches to CMB windshield - see pg. 5 Compass housing & mounting bracket - less compass - attaches to CMB windshield - see pg. 5		
326	Windshield s/n 21058716 thru 21058818 s/n T210-0001 thru T210-0197	.250	1213400-200
391	Front door window - left s/n 21057841 thru 21058714	.125	0711051-6
068	Front door window - left s/n 21058715 thru 21058818 s/n T210-0001 thru T210-0197	.250	0711051-9
392	Door window - right - outer - nonopenable	.125	0717010-16
	(continued)		

NEW	LP#	DESCRIPTION	THICKNESS	OEM PART NO.
-----	-----	-------------	-----------	--------------

CESSNA CENTURION 210 s/n 21057841 thru 21058818, 1962 thru 1966 (Continued)
s/n T210-0001 thru T210-0197 (Continued)
s/n 21058511 thru 21058715 (Continued)

069	Door window - right - inner - nonopenable* - PMA Pending * s/n 21058715 thru 21058818.080 s/n T210-0001 thru T210-0197			1211061-54
420	Rear baggage door window - left s/n 21057841 thru 21058191	.125		1211448-7
217	Rear baggage** door window - left - outer ** s/n 21058192 thru 21058818 s/n T210-0001 thru T210-0197	.125		1211448-24
070	Rear baggage door window - left - inner*** *** s/n 21058716 thru 21058818 s/n T210-0001 thru T210-0197	.100		1211061-47
220	Center forward window - left or right - outer	.125		1211400-16
072	Center forward window - left or right - inner**** **** s/n 21058715 thru 21058818 s/n T210-0001 thru T210-0197	.100		1211061-57
221	Rear window - right - outer	.125		1211400-14
071	Rear window - right - inner s/n 21058715 thru 21058818 s/n T210-0001 thru T210-0197	.100		1211061-58
222	Rear windshield - center	.125		1211400-19
223	Rear windshield - left	.125		1211400-17
224	Rear windshield - right	.125		1211400-18
381	Landing light lens	.080		0722100-4

CESSNA CENTURION 210 s/n 21058819 thru 21059199, 1967 thru 1969
s/n T2100198 thru T2100454

066	Windshield s/n 21058819 thru 21058936 s/n T2100198 thru T2100304	.250		1213700-5
067	Windshield s/n 21058937 thru 21059199 s/n T2100305 thru T2100454	.250		1213388-1
068	Front door window - left	.250		0711051-9
392	Front door window - right - outer	.125		0717010-16
069	Front door window - right - inner - PMA Pending	.080		1211061-54
217	Baggage door window - outer	.125		1211448-24
070	Baggage door window - inner	.100		1211061-47
221	Rear window - right - outer	.125		1211400-14
071	Rear window - right - inner	.100		1211061-58
220	Center window - left or right - outer	.125		1211400-16
072	Center window - left or right - inner	.100		1211061-56
075	Rear windshield	.125		1211349-1
074	Landing light lens - PMA Pending	.100		1221060-1

CESSNA CENTURION 210 s/n 21059200 and up, 1970 and up

067	Windshield s/n 21059200 and up	.250		1213388-1
068	Door window - left	.250		0711051-9
392	Door window - right - nonopenable - outer	.125		0717010-16
069	Door window - right - nonopenable - inner - PMA Pending	.080		1211061-54
068	Door window - right - openable	.250		0711051-9
076	Rear window - left or right - outer	.125		1210532-1,-2
079	Rear window - left or right - inner	.080		1210533-1,-2
075	Rear windshield	.125		1211349-1

CESSNA 303 Crusader s/n T30300001 thru T30300312, 1982 thru 1984

1040	Windshield - left*			2513503-1
1041	Windshield - right*			2513503-2
1042	Left front pilot's cockpit side window			2511128-1
1043	Foul weather window (vent) - left*			2511124-1
1044	Right front emergency exit door side window			2511010-4
1045	#2, #3 cabin window, - left or right			2511010-1
1046	#4 Upper cabin door window - left*			2511010-5
1047	#4 Rear window - right * PMA Pending			2511010-6

NEW	LP#	DESCRIPTION	THICKNESS	OEM PART NO.
-----	-----	-------------	-----------	--------------

CESSNA 310 s/n 35000 thru 35546, 1955 thru 1957

536	Windshield	.125	0811700-57
536/CON	Windshield - STC Conversion - removes center strap - Compass does not mount on windshield.	.250	
536/CMB	Windshield - STC Conversion - removes center strap - Compass mounting block bonded to windshield, accepts compass used on S/N 310L0001 thru 310Q0291	.250	
541	Left front pilot window	.125	0811680-14
542	Vent window	.125	0811725-21
548	Door window - right front	.125	0811486-6
543	Rear window - left - outer	.125	0811690-25
545	Rear window - left - inner s/n 35263 thru 35546	.125	0811755-7
546	Rear window - right - outer	.125	0811690-26
547	Rear window - right - inner s/n 35263 thru 35546	.125	0811755-8

CESSNA 310 s/n 35547 thru 39299, 1957 thru 1960

336	Windshield	.250	0811702-1
336/CON	Windshield - STC Conversion - removes center strap - Compass does not mount on windshield.	.250	
336/CMB	Windshield - STC Conversion - removes center strap - Compass mounting block bonded to windshield, accepts compass used on S/N 310L0001 thru 310Q0291	.250	
331	Left front pilot window	.250	0811684-1
332	Vent window	.250	0811726-1
333	Door window - right front	.250	0811516-1
543	Rear window - left - outer s/n 35547 thru 35771	.125	0811691-1
335	Rear window - left - outer s/n 35772 thru 39299	.250	0811691-3
545	Rear window - left - inner	.125	0811755-7
334	Rear window - right - outer	.250	0811691-2
547	Rear window - right - inner	.125	0811755-8

CESSNA 310 s/n 310-0001 thru 310J0200, 1961 thru 1965

336	Windshield	.250	0811702-1
336/CON	Windshield - STC Conversion - removes center strap - Compass does not mount on windshield.	.250	
336/CMB	Windshield - STC Conversion - removes center strap - Compass mounting block bonded to windshield, accepts compass used on S/N 310L0001 thru 310Q0291	.250	
331	Left front pilot window	.250	0811684-1
332	Vent window	.250	0811726-1
333	Door window - right front	.250	0811516-1
946	Center emergency exit window - left - outer	.250	0811040-4
959	Center window - left - inner	.125	0811046-1
947	Center window - right - outer	.250	0811042-2
960	Center window - right - inner	.125	0811046-2
957	Rear window - left - outer	.250	0811043-1
961	Rear window - left - inner	.125	0811047-1
958	Rear window - right - outer	.250	0811043-2
962	Rear window - right - inner	.125	0811047-2

CESSNA 310 s/n 310K0001 thru 310N0198, 1966 thru 1968

336	Windshield - s/n 310K0001 thru 310K0245	.250	0811702-1
336/CON	Windshield - STC Conversion -s/n 310K0001 thru 310K0245 - removes center strap - Compass does not mount on windshield.	.250	
336/CMB	Windshield - STC Conversion -s/n 310K0001 thru 310K0245 - removes center strap - Compass mounting block bonded to windshield, accepts compass used on S/N 310L0001 thru 310Q0291	.250	
716	Windshield s/n 310L0001 thru 310N0198	.250	0813659-1
720	Left front pilot window	.250	0811202-200
721	Vent window	.375	0891107-4
333	Door window - right front	.250	0811516-1
723	Rear picture window - left - outer	.250	0811231-1
725	Rear picture window - left - inner	.100	0811232-1
724	Rear picture window - right - outer	.250	0811231-2
726	Rear picture window - right - inner	.100	0811232-2

NEW	LP#	DESCRIPTION	THICKNESS	OEM PART NO.
-----	-----	-------------	-----------	--------------

CESSNA 310 s/n 310P0001 thru 310Q1160, 1969 thru 1974

716	Windshield	s/n 310P0001 thru 310Q0291	.250	0813659-1
719	Windshield	s/n 310Q0401 thru 310Q1160	.250	0811702-3
720	Left front pilot window		.250	0811202-25
721	Vent window		.375	0891107-4
333	Door window - right front		.250	0811516-1
723	Rear window - left - outer		.250	0811231-1
725	Rear window - left - inner		.100	0811232-1
724	Rear window - right - outer		.250	0811231-2
726	Rear window - right - inner		.100	0811232-2
722	Rear windshield	s/n 310Q0401 and up	.125	0814218-2

CESSNA 310R s/n 310R0001 and up, 1975 thru 1981

719	Windshield	s/n 310R0001 thru 310R1200	.250	0811702-3
406	Windshield with compass base plate	s/n 310R1201 and up	.250	0813659-200
407	Compass base plate	s/n 310R1201 and up	.250	0813659-8
720	Left front pilot window		.250	0811202-25
721	Vent window		.375	0891107-4
333	Door window - right front		.250	0811516-1
723	Rear window - left - outer		.250	0811231-1
725	Rear window - left - inner		.100	0811231-2
724	Rear window - right - outer		.250	0811231-2
726	Rear window - right - inner		.100	0811232-2
722	Rear windshield		.125	0814218-2

CESSNA SKYKNIGHT 320 thru 320C s/n 320-0001 thru 320C0073, 1962 thru 1965

336	Windshield		.250	0811702-1
336/CON	Windshield - STC Conversion - removes center strap - Compass does not mount on windshield.		.250	
336/CMB	Windshield - STC Conversion - removes center strap - Compass mounting block on windshield, accepts compass used on s/n 320E0001 thru 320F0045		.250	
331	Left front pilot window		.250	0811684-2
332	Vent window		.250	0811726-1
341	Door window - right front		.250	0811516-2
161	#2 emergency exit window - left - outer		.250	0811040-10
163	#2 window - right - outer		.250	0811042-4
164	#2 window - right - inner		.100	0811046-4
982	#2 emergency exit window - left - inner		.100	0811046-3
983	#3 window - left - outer		.250	0811060-1
984	#3 window - left - inner		.100	0811059-1
985	#3 window - right - outer		.250	0811060-2
986	#3 window - right - inner		.100	0811059-2
987	#4 rear window - left - outer		.250	0811058-1
988	#4 rear window - left - inner		.100	0811057-1
989	#4 rear window - right - outer		.250	0811058-2
990	#4 rear window - right - inner		.100	0811057-2

CESSNA SKYKNIGHT 320D thru 320F s/n 320D0001 thru 320F0045, 1966 thru 1968

336	Windshield - s/n 320D0001 thru 320D0130		.250	0811702-1
336/CON	Windshield - STC Conversion - removes center strap - s/n 320D0001 thru 320D0130 - Compass does not mount on windshield.		.250	
336/CMB	Windshield - STC Conversion - removes center strap - s/n 320D0001 thru 320D0130 - Compass mounting block on windshield, accepts compass used on s/n 320E0001 thru 320F0045		.250	
716	Windshield	s/n 320E0001 thru 320F0045	.250	0811659-1
331	Left front pilot window	s/n 320D0001 thru 320D0130	.250	0811684-2
332	Vent window	s/n 320D0001 thru 320D0130	.250	0811726-1
720	Left front pilot window - PMA Pending	s/n 320E0001 thru 320F0045	.250	0811208-201
721	Vent window	s/n 320E0001 Thru 320F0045	.375	0891107-5
341	Door window - right front		.250	0811516-2
161	Emergency exit window - left - outer	s/n 320D0001 thru 320D0130	.250	0811040-10
	(continued)			

NEW	LP#	DESCRIPTION	THICKNESS	OEM PART NO.
-----	-----	-------------	-----------	--------------

CESSNA SKYKNIGHT 320D thru 320F (Continued)

567	Emergency exit - PMA Pending window - left - outer	s/n 320E0001 thru 320F0045	.250	0811285-6
162	Emergency exit window - left - inner		.100	0811046-5
163	#2 window - right - outer		.250	0811042-4
164	#2 window - right - inner		.100	0811046-6
165	#3 window - left - outer		.250	0811175-1
166	#3 window - left - inner		.100	0811176-1
167	#3 window - right - outer		.250	0811175-2
168	#3 window - right - inner		.100	0811176-2
169	Rear window - left - outer		.250	0811173-1
170	Rear window - left - inner		.100	0811174-1
171	Rear window - right - outer		.250	0811173-2
172	Rear window - right - inner		.100	0811174-2

CESSNA SKYMASTER 336 s/n 336-0001 thru 336-0195, 1964

729	Left front pilot window		.187	1411312-3
741	Vent window		.250	1513700-3
749	Emergency exit window		.125	1400057-28
752	Door window - right front		.250	1411312-2
730	Center window - left		.187	1412312-1
730	Center window - right		.187	1412312-2
747	Rear window - left		.250	1412312-5
747	Rear window - right		.250	1412312-6
713	Landing light lens - left - PMA Pending		.100	1422599-1
714	Landing light lens - right - PMA Pending		.100	1422599-2

CESSNA SUPER SKYMASTER 337 s/n 337-0001 thru 33701462, 1965 thru 1972

REIMS AVIATION F337 s/n F33700001 thru F33700055, 1970 thru 1972

728	Windshield		.250	1413702-3
729	Left front pilot window - outer		.187	1411312-3
753	Left front pilot window - inner		.100	1511004-2
741	Vent window		.250	1513700-3
749	Emergency exit window		.125	1400057-28
752	Door window - right front		.250	1411312-4
730	Center window - left - outer		.187	1412312-3
737	Center window - left - inner		.100	1512004-7
730	Center window - right - outer		.187	1412312-4
737	Center window - right - inner		.100	1512004-8
747	Rear window - left - outer		.250	1412312-5
740	Rear window - left - inner		.100	1512004-5
747	Rear window - right - outer		.250	1412312-6
740	Rear window - right - inner		.100	1512004-6
713	Landing light lens - left - PMA Pending		.100	1422599-1
714	Landing light lens - right - PMA Pending		.100	1422599-2

CESSNA SUPER SKYMASTER 337 s/n 33701463 thru 33701952, 1973 thru 1980

REIMS AVIATION F337 s/n F33700056 thru F33700086, 1973 thru 1978

775	Windshield		.250	1513770-1
729	Left front pilot window - without emergency exit - outer		.187	1411312-3
757	Left front pilot window - without emergency exit - inner		.100	1511161-1
756	Left front pilot window - emergency exit - outer		.187	1400057-4
758	Left front pilot window - emergency exit - inner		.100	1511161-2
741	Vent window		.250	1513700-3
759	Door window - right front - outer		.187	1517102-1
760	Door window - right front - inner		.100	1511160-1
762	Center window - left or right - outer		.187	1512063-9
765	Center window - left or right - inner		.060	1511159-3
764	Rear window - left or right - outer		.187	1512063-11
766	Rear window - left or right - inner		.060	1511159-4

NEW	LP#	DESCRIPTION	THICKNESS	OEM PART NO.
-----	-----	-------------	-----------	--------------

CESSNA 340 s/n 340-0001 thru 340-0555
340A s/n 340A0001 thru 340A1817, 1972 thru 1984

SP-PRIKT	Window Inspection Prism Kit			
1060	Windshield - left			5311266-201
1061	Windshield - right			5311266-200
1062	Left front pilot window	s/n 340-0001 thru 340-0300		5311261-201
1063	Left front pilot window	s/n 340-0301 thru 340A1500		5311261-11
1071	Left front pilot window	s/n 340A1501 thru 340A1817		5311261-215
1064	Foul weather window (vent) - left	s/n 340-0001 thru 340-0300		5311271-1
1065	Foul weather window (vent) - left	s/n 340-0301 thru 340A1817		5311277-5
1066	Right front co-pilot window	s/n 340-0001 thru 340-0210		5311261-202
1067	Right front co-pilot window	s/n 340-0211 thru 340A1500		5311261-10
1072	Right front co-pilot window	s/n 340A1501 thru 340A1817		5311261-216
1068	Foul weather window (vent) - right			5311277-6
1156	Right #2 Emergency exit & #3 cabin, left #2 & #3 cabin window			5111605-2
1162	Right #2 Emergency exit & #3 cabin, left #2 & #3 cabin window - inner			5111605-6
1069	Left #4 cabin door window, right #4 cabin window			5311261-205
1163	Left #4 cabin door window, right #4 cabin window - inner			5111605-11
1157	#5 Rear window - left or right			5111605-1
1164	#5 Rear window - left or right - inner			5111605-5
689	Navigation light cover - left* - use where NAV and strobe lights are installed		.080	0823411-13
679	Navigation light cover - right* - use where NAV and strobe lights are installed * PMA Pending		.080	0823411-14

CESSNA 401/402 thru 402(B) s/n 401/402-0001 thru 402B0249, 1967 thru 1972

754	Windshield - left		.250	5011162-3
755	Windshield - right		.250	5011162-4
993	Left front pilot window		.250	5011177-9
691	Left front pilot window - crew door equipped	s/n 402A0001 thru 402B0249	.250	5211346-12
994	Right front window		.250	5011177-10
694	Foul weather window (vent) - left		.500	5011167-57
695	Foul weather window (vent) - right		.500	5011167-58
032	#2 side window - left		.187	5011135-4
032	#3 side window - left		.187	5011135-4
032	#2 side emergency exit window - right		.187	5011135-4
032	#3 side window - right		.187	5011135-4
033	#4 side window - right		.187	5011135-8
031	#5 rear window - right		.187	5011135-16
035	#5 rear window - left		.187	5011135-12
030	Cargo door window		.187	5011277-4
034	Upper cabin door window		.187	5011190-5
689	Navigation light cover - left - use where NAV and strobe lights are installed		.080	0823411-13
679	Navigation light cover - right - use where NAV and strobe lights are installed		.080	0823411-14

CESSNA 402(B) s/n 402B0301 thru 402B1384, 1973 and up
402(C) s/n 402C0001 thru 402C0355
402(C) s/n 402C0401 and up

754	Windshield - left		.250	5011162-3
755	Windshield - right		.250	5011162-4
993	Left front window		.250	5011177-9
691	Left front window -crew door equipped or framed for crew door		.250	5011346-12,-17
994	Right front window	s/n 402B0301 thru 402B1384	.250	5011177-10
693	Right front window - acrylic window only	s/n 402C0001 and up	.250	5091106-10
694	Foul weather window (vent) - left		.500	5011167-57
684	Upper cabin - door window - left	s/n 402B0301 thru 402C0286	.187	5211190-6
742	Upper cabin - door window - left	s/n 402C0287 and up	.187	5211134-5
695	Foul weather window (vent) - right		.500	5011167-58
682	#2 side window - left		.187	5211135-17
696	#2 escape hatch window - right		.187	5211130-13
683	#3 side window - left		.187	5211135-13
697	#3 side window - right		.187	5211135-16
687	#4 side window - right		.187	5211135-12
685	#5 side window without cargo door - left		.187	5211135-9
	(continued)			

NEW	LP#	DESCRIPTION	THICKNESS	OEM PART NO.
-----	-----	-------------	-----------	--------------

CESSNA 402(B) s/n 402B0301 thru 402B1384, 1973 and up (Continued)

402(C) s/n 402C0001 thru 402C0355 (Continued)

402(C) s/n 402C0401 and up (Continued)

688	#5 side window - right		.187	5211135-8
686	#6 rear window - left	s/n 402B0301 thru 402C0286	.187	5211135-5
744	#6 rear window - left	s/n 402C0287 and up	.187	5211134-9
699	#6 rear window - right	s/n 402B0301 thru 402C0286	.187	5211135-4
745	#6 rear window - right	s/n 402C0287 and up	.187	5211134-10
685	Cargo door window - left	s/n 402B0301 thru 402C0286	.187	5211135-9
743	Cargo door window - left	s/n 402C0287 and up	.187	5211134-7
689	Navigation light cover - left	s/n 402B0301 thru 402B1384	.080	0823411-13
679	Navigation light cover - right	Use where NAV and strobe lights are installed s/n 402B0301 thru 402B1384	.080	0823411-14

CESSNA TITAN, FREIGHTER, COURIER, AMBASSADOR 404 s/n 404-0001 thru 404-0856, 1977 thru 1981

754	Windshield - left		.250	5011162-3
755	Windshield - right		.250	5011162-4
691	Left front window		.250	5211346-14
994	Right front window		.250	5011165-4
694	Foul weather window (vent) - left		.500	5011167-57
695	Foul weather window (vent) - right		.500	5011167-58
665	#2 window - left		.187	5811152-1
666	#2 window - right		.187	5811152-2
667	#3 emergency exit window - right		.187	5811377-1
665	#3 window - left		.187	5811152-1
668	#4 cargo door window - left		.187	5811152-3
669	#4 window - right		.187	5811152-4
672	#5 cabin door window - left		.187	5811152-5
673	#5 window - right		.187	5811152-6
674	#6 window - left		.187	5811152-7
675	#6 window - right		.187	5811152-8
676	#7 Rear window - left		.187	5811152-9
699	#7 Rear window - right		.187	5811152-10

CESSNA 411 & 411A s/n 411-0001 thru 411A0300, 1965 thru 1968

754	Windshield - left		.250	5011162-3
755	Windshield - right		.250	5011162-4
993	Left front window	s/n 411A0251 thru 411A0300	.250	5011177-9
994	Right front window	s/n 411A0251 thru 411A0300	.250	5011177-10
694	Foul weather window (vent) - left		.500	5011167-57
695	Foul weather window (vent) - right		.500	5011167-58
032	#2 window - left		.187	5011135-4
032	#2 emergency exit window - right		.187	5011135-4
032	#3 window - left		.187	5011135-4
032	#3 window - right		.187	5011135-4
034	#4 cabin door window - left		.187	5011190-5
033	#4 window - right		.187	5011135-8
035	#5 rear window - left		.187	5011135-12
031	#5 rear window - right		.187	5011135-16
030	#5 cargo door window - left		.187	5011277-4

CESSNA 414, Chancellor 414A

s/n 414-0001 thru 414A1212, 1970 thru 1984

421, Golden Eagle 421A thru 421C

s/n 421-0001 thru 421C1807, 1968 thru 1985

425 Corsair

s/n 425-0001 thru 425-0234, 1980 thru 1985

SP-PRIKT	Window Inspection Prism Kit			
1150	Windshield - left - non heated			5111604-203
1151	Windshield - right			5111604-202
1152	Left front pilot cockpit side window			5111605-3
1153	Right front co-pilot cockpit side window			5111605-4
1154	Foul weather window (vent) - left			5111603-5
1155	Foul weather window (vent) - right			5111603-6
1156	#2 Cabin, #3 cabin, #4 cabin door window - left (continued)			5111605-2

NEW

LP#	DESCRIPTION	THICKNESS	OEM PART NO.
-----	-------------	-----------	--------------

CESSNA 414, Chancellor 414A, 421, Golden Eagle 421A thru 421C, 425 Corsair (Continued)

1156	#2 Emergency exit, #3 cabin, #4 cabin window - right		5111605-2
1162	Left #2, #3 cabin, & #4 cabin door - inner		5111605-6
1162	Right #2 emergency exit, #3 & #4 cabin window - inner		5111605-6
1157	#5 Rear window - left or right*		5111605-1
1164	#5 Rear window- left or right - inner*		5111605-5
1158	#5 Cabin window - left**		5111605-9
1159	#5 Cabin window - right**		5111605-10
1163	#5 left or right cabin window - inner**		5111605-11
1160	#6 Rear window - left**		5111605-13
1161	#6 Rear window - right**		5111605-14
1164	#6 Rear window - left or right - inner**		5111605-5
689	Navigation light cover - left - PMA Pending - use where NAV and strobe lights are installed	.080	0823411-13
679	Navigation light cover - right - PMA Pending - use where NAV and strobe lights are installed	.080	0823411-14
	* 414 421 thru 421B	s/n 414-0001 thru 414-0350 s/n 421-0001 thru 421B0300	
	** 414 & 414A 421B & 421C 425	s/n 414-0351 thru 414A1212 s/n 421B0301 thru 421C1807 s/n 425-0001 and up	